

HOW TO MEASURE FOR A ROMAN BLIND

Version. 1 (Nov. 18)

- Please use a metal tape and refer to the useful guidance & important check points below.
- Please provide the data in cm.

<For fitting inside the recess>

1. Measure the drop at 3 points; left, centre and right. The smallest drop is to be used as the drop measurement.
2. Measure the width at 3 points; the top, centre and the bottom. The smallest width is to be used as the width measurement.

<For fitting outside the recess>

1. The width of the blind is the width of the sill or window + 2.5 to 10cm each side.
2. The fitting height is either on the frame or 5 to 20cm above the window.
The lower edge of the blind should be to or just below the sill.

<General>

1. For your reference for later, on which side of the blind would you like the chain?
(Left / Right)
2. If you are planning to fix your Roman blind headrail by yourself, please check the surrounding area to see if there might be pipes or cables in the wall or the surface you will be drilling into to fix the headrail is suitable for the purpose, etc.

